



## Vintage Overlay

### Installation Instructions

Install in a dust-free environment. Do not touch the application side of the Vintage Overlay, and do not touch the radio display before or during installation.

**Step 1:** Clean the radio display with a soft, lint-free cloth to remove any oil or dirt.

**Step 2:** Slowly peel off the film labeled "1" from the application side of the Vintage Overlay. Carefully apply the application side of the Vintage Overlay to your radio display.

**Step 3:** Remove any air bubbles that may have formed by gently rubbing with a credit card or lint-free cloth (be sure not to rub too hard, or you may rub the ink off of the Vintage Overlay). If dust gets trapped beneath the Vintage Overlay, see the reverse side of this guide for troubleshooting instructions.

**Note:** These Vintage Overlays cannot completely protect your radio display from all scratches, abrasions or from damage resulting from impacts to the display.

## Troubleshooting Instructions

### Removing Dust From Beneath the Vintage Overlay

**Step 1:** Place a piece of adhesive tape on the corner of the Vintage Overlay closest to the dust particle or air bubble and lift up.

**Step 2:** Use a second piece of adhesive tape to remove the dust particle.

**Step 3:** Lay the Vintage Overlay back down on the screen and remove any air bubbles that may have formed (see reverse for instructions).

**Step 4:** Remove the adhesive tape.

### Realigning the Vintage Overlay

**Step 1:** Place a piece of adhesive tape on the corner of the Vintage Overlay and lift up. Do not touch radio display or the application side of the Vintage Overlay.

**Step 2:** Carefully realign the edge of the Vintage Overlay with the radio display.

**Step 3:** Remove any air bubbles that may have formed (see reverse for instructions).